

LUCA PENDANT

INSTALLATION INSTRUCTIONS

1 OF 5

BARONCELLI ⌘



WHAT IS INCLUDED

1. Ceiling canopy
2. Suspension cable
3. Spares

WHAT YOU WILL NEED

1. Ceiling fixings
2. Bulbs (G9 Bi Pin MAX 60W)
3. Screwdriver (3.5mm / 1/8" flat tip) + pliers
4. Soft cloth

WEIGHT


1 light 2KG (9lb)

LUCA PENDANT

INSTALLATION INSTRUCTIONS

2 OF 5


BARONCELLI ⌘



STEP 1


Release side screws from fitting and remove bracket. Secure bracket into ceiling beam or joist capable of holding the weight of the piece.

NOTE : CEILING FIXINGS ARE NOTE SUPPLIED




STEP 2

Pass suspension cable in through outer holes and up through the small stem of the light fitting. Use a silicone O-ring to hold the electrical and suspension cable together.



STEP 3

Pass suspension cable up through gripper in ceiling canopy. Set height and feed electrical cable up through barrel in canopy.



STEP 4


Remove excess cable and make electrical connection.

LUCA PENDANT


INSTALLATION INSTRUCTIONS

3 OF 5

BARONCELLI ⌘



STEP 5
Secure ceiling canopy in position using side screws.
Insert bulb and test.




STEP 6
Raise glass up around metal fitting. Secure using
x2 screws fastening through the holes in glass and
into the metal casing. Ensure a silicone O-ring is
used between the pin head and glass.

ENSURE ANY ELECTRICAL WORK IS CARRIED OUT BY A QUALIFIED ELECTRICIAN

OPERATION AND MAINTENANCE

4 OF 5

BARONCELLI ⌘




GLASS CLEANING

Glass elements should be carefully cleaned using a soft cloth.

METAL CLEANING

Carefully clean metal surfaces using a soft cloth and no liquid.



REPLACING A BULB


Remove glass element first, unscrew bulb and remove.

ENSURE ANY ELECTRICAL WORK IS CARRIED OUT BY A QUALIFIED ELECTRICIAN


OPERATION AND MAINTENANCE

5 OF 5


BARONCELLI ⌘




STEP A
TROUBLE SHOOTING - ELECTRICAL FAULTS
Check fusebaord



STEP B
TROUBLE SHOOTING - ELECTRICAL FAULTS
Check and replace the bulbs. Retrace installation steps to access.



STEP C
TROUBLE SHOOTING - ELECTRICAL FAULTS
Check/test lamp holder. Retrace installation steps to access.



STEP D
TROUBLE SHOOTING - ELECTRICAL FAULTS
Lower ceiling canopy. Check /test electrical connections between light and mains supply.